



Dynalite Driver
Installation Manual

Contents

Introduction	3
Before You Begin	3
Setting Up Envision Gateway	3
Installation	4
Dynamalite Gateway Driver	5
Dynamalite Dimmer Driver	5
Dynamalite Switch Driver	5
Dynamalite Relay Driver	6
Dynamalite Trigger Driver	6
Dynamalite Blind Driver	6

Introduction

This Dynalite driver for Control4, supports many features, and supports many of the ways in which Dynalite is programmed. It can communicate with Dynalite through RS-232 or IP communication.

To use this driver, you will need to know the Areas/Channels/Presets used by the Dynalite system. If they are not known, you can find them out through the Debug of the driver, but this will require much more installation time. The preferred way is to get this information of the Dynalite System Programmer.

It is important to trial this driver before installing it at a customer's house, to understand the setup process, and the various ways to work with the driver.

Before You Begin

Before you begin trying to program/setup the driver, ensure that you have setup your Dynalite interface correctly. If you are using a DMNG-232 interface, ensure that it has been setup for Dynet1 communication. If you are using some form of RS232-RS485 converter, there is no special setup required.

If you are using an IP connection with an Envision Gateway, ensure the gateway has been setup on a static IP address, and that a port has been setup specifically for Control4. The Envision Gateway supports multiple ports, and only allows 1 device to connect on each port. You will want to have 2 ports minimum setup on the Envision Gateway, one will be used for the Dynalite programming software, and the other will be used for Control4.

Ensure the Envision Gateway has been setup for the Dynet1 protocol to work with this driver.

If you are unsure about this, speak to the Dynalite programmer to set these options up for you.

Setting Up Envision Gateway

id	00:17:88:0B:63:75
s	True
	192.168.216.186
	fe80::217:88ff:fe0b:6375
icast service	Enabled

Copy	Paste
ction	Description
	Baudrate: 9600
<	UDP Client, IP: 255.255.255.255, Por...
<	TCP Server, Port: 50000
<	TCP Server, Port: 50001

Port	
Port type	DyNet2
Mode	Server
Port Number	50001
Protocol	TCP
Flags	
Connection	Trunk
Area zero transmit	Disabled
Sign on at start up	Enabled

Example port setup for System Builder software connection (Dyralite programmer's connection)

id	00:17:88:0B:63:75
s	True
	192.168.216.186
	fe80::217:88ff:fe0b:6375
icast service	Enabled

Copy	Paste
ction	Description
	Baudrate: 9600
:	UDP Client, IP: 255.255.255.255, Por...
>	TCP Server, Port: 50000
:	TCP Server, Port: 50001

Port	
Port type	DyNet1
Mode	Server
Port Number	50000
Protocol	TCP
Flags	
Connection	Trunk
Area zero transmit	Disabled
Sign on at start up	Enabled

Example port setup for Control4 system connection

Delete Routing | Copy | Paste | Route RS485 and Default Multicast Service

	To	Filters
Port 1, Spur	IPv4 Port 2, Trunk, TCP Server, Port: 50000	No filter
Port 2, Trunk, TCP Server, Port: 50000	Comm Port 1, Spur	No filter
Messages	IPv4 Port 2, Trunk, TCP Server, Port: 50000	No filter
Collection	IPv4 Port 2, Trunk, TCP Server, Port: 50000	No filter
Port 1, Spur	IPv4 Port 3, Trunk, TCP Server, Port: 50001	No filter
Port 3, Trunk, TCP Server, Port: 50001	Comm Port 1, Spur	No filter
Collection	IPv4 Port 3, Trunk, TCP Server, Port: 50001	No filter
Messages	IPv4 Port 3, Trunk, TCP Server, Port: 50001	No filter
Port 2, Trunk, TCP Server, Port: 50000	IPv4 Port 3, Trunk, TCP Server, Port: 50001	No filter

Delete Filter | Copy All | Paste

Name	Operation

Example port routing setup so both ports work correctly:

Installation

Once you have placed the drivers in to 'Documents/Control4/Drivers' on your computer, you will be able to find them within Composer's driver search tab. From the manufacturers drop down menu, select 'Dynamlite' and this will list the available drivers.

Dynamlite Gateway Driver

You should add this driver in first, to ensure all the other drivers link to this one automatically. Once added, you can enter the license key into the license key field, and allow the driver to activate. You will require internet for activation of the driver.

If you are using IP control, you can set the IP address and port of the IP interface module. The connection status should show that it is now connected. (It may take up to 60 seconds for the connection)

If you are using RS-232 control, go into the connections of Composer, and link the Serial connection of this driver to the Serial port it's connected to.

The 'Request Levels' option may be set to true, for the drivers to show exact level when Preset messages are called or a 'Stop Ramp; message is used. This option gets the driver to request the level of lights when they are set. Be aware this will add extra traffic to the Dynet network. We have aimed to keep traffic to a minimum.

Dynamlite Dimmer Driver

This driver supports various Dynamlite Area/Channel Ramp commands. This driver doesn't support sending Presets, if you need to send Preset messages, please use the Dynamlite Switch Driver.

From the Opcode dropdown menu, select the desired option. If you want LEDs on Dynalite keypads to match the status on Control4 navigators, it is important to choose the same Opcode as sent by the Dynalite keypad.

Set the Area property to the corresponding area, note that Area 0 means ALL areas. Be careful if you use Area 0 as it will control all the loads on the Dynalite Network.

Set the Channel to the corresponding channel, if you wish to control a whole area, set the Channel to 256.

Set the default Fade Time for the driver, this can be overridden by Fade Time set within an Advanced Lighting Scene.

You can set the Join Bits as required, by default the driver has all Join Bits set.

The Preset 1-8 properties are to inform the driver what level it should update the Navigators to when it hears a Preset message for the particular Area/Channel. It will take a value of 0 (0%) – 254 (100%), or 255 which is to ignore the Preset.

Depending on the "Request Levels" setting in the gateway will decide if these are used. If "Request Levels" is set to true, then the gateway will request the actual light level, so there is no need to use these values. If you need to minimise traffic on the Dynet bus, then these can be used as default feedback when a Preset is sent.

Dynalite Switch Driver

This driver supports various Area/Channel commands, as well as Preset commands.

From the Opcode dropdown menu, select the desired Opcode, if you are after Presets, then you will use one of Opcode 6B,65 or 00-03,0A-0D.

The Area/Channel properties are used as in the Dimmer driver above, as well as the Fade Time, Preset 1-8 and Join Bit properties. If you are using one of the Preset Opcodes, you don't need to worry about the Preset 1-8 properties.

This driver has the addition of On/Off Preset properties. These are used in conjunction with the Preset Opcodes, and are the presets sent when this Driver turns On/Off.

This driver will show as being ON, on the Navigators only when it's On Preset is active. If any other preset is activated (even if it's not the Off Preset), then this driver will update as being Off.

Dynalite Relay Driver

This driver supports various Area/Channel commands, it enables you to connect a generic motorisation driver (Gate, Door Lock, etc) to the Dynalite network.

The properties are set as mentioned for the Switch/Dimmer Driver.

Dynalite Trigger Driver

This driver allows you to trigger events within Control4, from the Dynalite keypads. This opens up the possibility of doing source selections, volume control etc, from Dynalite Keypads.

In the properties you set the Area which this driver will listen on, and then within Control4's programming section, you can program when various Dynalite Presets are activated in that area.

The use of this driver will require particular programming on the Dynalite keypads to send Preset messages. The driver will listen for Presets 1-200.

Dynalite Blind Driver

This driver allows you to control blinds within Control4. There are many different ways to control blinds within Dynalite, at the moment this driver allows you to enter a custom Dynalite message for the UP/DOWN/STOP, so as to support the various blind control methods.

The custom messages should be entered as a comma separated list of hex bytes, excluding the checksum byte. Some examples:

5C,80,01,10,01,00,00 - This message will start a task

1C,01,01,80,FF,64,FF - This message will ramp a channel/area level.

This blind driver doesn't currently feedback intermediate blind positions to navigator.