

To Update Firmware

1. Download the files in this folder called
 - 'Click Me to Update' ← a batch file
 - 'Updater' ← a Windows .exe
 - sdXXX.eeprom ← the raw firmware file. Version numbers will increment as development continues.
2. Connect DMX engine to a PC using a serial cable. Pin 4 (DTR) must be present for the firmware to load.
3. Double click on the 'Click Me to Update.bat' file. Update takes about ten seconds. You may need to authorize Windows to allow this file to run.
4. System will restart
5. Connect the DMX Engine back to the Control4 Controller and current firmware version will be displayed in the Control4 Driver properties.